

The test fitting can be used to check set pressure by opening the valve. Lock up would be tested with the stop closed. The fitting can be used to test lines at pounds or inches water column. The stop also acts as a safe place to bleed pressure down.

MAXIMUM WORKING PRESSURE IS 100 PSI

Use Test Fitting

1. Hold adapter with wrench and turn meter ring
2. Attach gauge to adapter
3. Turn gas on at meter stop
4. Open valve on test fitting and set pressure
5. Turn valve off and you will have lock-up pressure. Watch gauge of leak-through for a short period of time