

# KUHLMAN MODEL 3000 LEAK CHECKER

## OPERATING INSTRUCTIONS

### TO DETECT LEAK:

1. Hook line to system.
2. Both Valves are CLOSED.
3. OPEN Valve No. 1.
4. CLOSE Valve No. 2.
5. Pump up Tank and System to desired test pressure.
6. OPEN Valve No. 2.
7. CLOSE Valve No. 1.
8. The air in the Test Tank should adjust to the surrounding temperature before making a test.

If there is a leak in the system, fluid will travel up either side of tubing.

To remove LEAK CHECKER from system be sure both valves are OPEN.

## FILLING INSTRUCTIONS

1. Remove plastic tube from fitting on VALVE No. 2.
2. Insert approximately 1/2 to 1 inch of fluid into tube.
3. Replace tube and tighten fitting.
4. Use only Kuhlman Instrument Fluid available at Factory.